
CALL LOGS	2
CONTACTS	4
MULTIMEDIA	6
MESSAGE.....	9
TOOLS	12
APPLICATION	14
FILE MANAGEMENT	15
SETTINGS	16

Call logs

You can view your recent call situation.

[Dialed calls]: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.

[Received calls] :Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency,

[Missed calls] :Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.

[Rejected calls] Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.

Press the OK soft key to enter the options menu can be more than the number of call records in the following:

-
- ◆ Details: View the current record date, time, type.
 - ◆ Call: call the current number.
 - ◆ Save: You can save the current record to the phone or SIM card
 - ◆ Send Message: send the current record of SMS or MMS
 - ◆ Add to existed contacts: the number of the record the name added to the existing record which
 - ◆ Add to blacklist: the current record to reject a call which
 - ◆ Delete: Delete the currently selected record
 - ◆ Delete All: delete all call records

[Delete all]: Delete all call records

[Call times]: Last time zero starting time for last call statistics, a total of dialed calls, received calls, all calls total, all the time can also be zero.

[Call cost]

- ◆ Total cost: check the total call charges
- ◆ Max cost: set the call limit
- ◆ Price per unit: Edit SIM phone rates.
- ◆ Reset cost: be clear on the meter

Contacts

You have 2 phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 500 phone numbers and the SIM card's capacity depends on its type.

In standby mode, enter a number, press the call key pieces to make a call, press the OK key to save

◆ If 'To SIM 1/2' is selected, users can edit name and number.

◆ If 'To phone' is selected, the user can edit the name, mobile number, home number, e-mail address, image, ringtone, caller groups

Into the phone book list, the list on the left displays a small icon indicates that the record exists SIM card or mobile phone, the right is the record of the name and number information.

Standby mode, press the right soft key to enter into the

address book or from the menu

Into the address book, do the following:

[New]: Selection into the select group interface: into the phone or SIM card.

[Search]: Enter the contact name and press the Enter key to find

[Write Message]: Choose to write messages into the appropriate function interface

[Call]: Choose to allocate or direct IP dialing

[Send vCard]: Send vCard with MMS/Bluetooth

[Delete]: choose to delete the selected contact record

[Mark]: marker-all or the currently selected record

[Copy]: Select Copy to SIM, or cell phone or storage card

[Others]

[Speed dial settings]: start and set the speed dial

[Caller ID]: Query and edit the phone numbers

[Memory status]: Query the current SIM card and mobile phone storage capacity

[Single line display]: ring Contact records show single or

double lines

Multimedia

【Camera】: The phone supports photo, so you can capture your favorite scenes anywhere. Photos will be saved in the phone comes with a file system, photographs as JPG format, you can phone provides photographs sent to a computer via USB connection to view, can also be set Image for the standby

Note: This function can work without driver under Windows XP by directly connecting your mobile to the computer

[Gallery]: View the pictures

[Settings] Set camera parameters

[Storage]: Choose a photo is stored

【Audio player】

Play audio files, MP3 songs; to play audio files, MP3 songs, press the Up and Down keys to adjust the volume, press the left and right keys to select the present, the next song, press the OK button for the on / off Music

[Music list]: Into playlist interface. Can be added to the play list editing and other operations

[Music mark]: Bookmarks in the music songs in the operations (including play / delete / multiple selection delete / rename / details and other operations)

[Add]: Add songs or music playlist bookmark

[Set as ringtone]: The song is set to call or alarm tone

[Play mode]: Select play modes: single repeat, all repeat or random

[Settings]:

◆ Equalizer: Choose a variety of equalizer effects

◆ Display setting: Select Open the Spectrum

[Open review] Function of review

[Exit]: Exit menu audio player

【Video player】

[Play list] list stored in the player's video files

◆ Play: Play the selected video file

-
- ◆ Add video: side the storage space from the phone to add video files
 - ◆ Update list: update the current playlist
 - ◆ Delete from list: Delete the currently selected from the list of video files
 - ◆ Details: View detailed information on the currently selected video
 - ◆ Set as: Set for the switch machine animation
 - ◆ Mark: Select a single tag or all, and then operate
- [Full screen play] full-screen video playback on the current
- [Order play] Select whether to open the playlist on the current order of play inside the video file
- [Video application] set to turn off the animation or animation
- [File attribute] View the current video for more

information.

【FM radio】

[Auto search and save]: Channel auto search and save

[Channel list]: View channel list

[Save]: Save the channel to the channel list

[Manual search]: Manually enter the channel and find

[Open speaker] Choose whether to open the microphone

[background play] Choose whether to open the Background Play

[Help]: FM Help

Message

The Messaging function is a network service. Sending and receiving Text/MMS can only be used if the service is proposed by your network operator.

You can send ordinary Text messages, enhanced Text messages (Text messages containing pictures, ring tones

and animation as attachments, EMS for short). The SMS is sent to the Text messages center in the network firstly, and then to the target user. If the receiver's mobile is power off or cannot receive messages, the network will store the message temporarily and the store duration is determined by the user configuration and the service provider. I

The message will be directly stored in the SIM card if the capacity is not full. A blinking icon at the head row of the main screen will be displayed if the capacity is full.

Messages unread

If the Text message has been sent to the receiver, a beep will sound. (If the tone for Text messages and message report are activated).

[Write message]

[New SMS]

- ◆ Send: Enter the appropriate number of the recipient or from the phonebook add

-
- ◆ Insert template: to the content of the message currently being edited into the common language
 - ◆ Add contact info: Insert the contact person
 - ◆ Add phiz emoticons into the meaning of the representative
 - ◆ Save: will save the information to Drafts

[Inbox]:

- ◆ Reply: reply to SMS to each other.
- ◆ Delete: Delete short message
- ◆ Call: choose a voice call or a call to the sender IP calls
- ◆ Lock: lock can not be deleted
- ◆ Mark: single marker or markers in whole or in text messages stored in SIM1/SIM2, mark or unmark after delete records

-
- ◆ Sort: In accordance with time / contact / theme / message type sort
 - ◆ Delete repeated number: choose to delete the same number of records.

[Outbox]: Reading or processing stored in the Outbox of the SIM card message.

[Drafts]: Reading or processing stored in the Drafts of the SIM card message

[Sentbox]: read and process the mail stored in the SIM card has been sent information

Tools

[Alarm]

This machine has three alarm times available for your settings. Access any time, you can set its status to on / off, ring time, repeat mode, ring tones, alarm clock name, etc.

[Calendar]: Press the left soft key to access the calendar display interface, the first line shows the year, month, and

the third line shows the week, the middle section shows the specific date of a month, the last line shows the right and left soft key in the message. Interface in the calendar, press the arrow keys on the date forward one week, press the arrow keys to move one week after the date, press the left arrow key date forward one day, press the right arrow keys to move the day after the date, select the date to a dark display

[Add task]: a new agenda

[View tasks]: View the schedule one day save

[All tasks]: View the schedule all day

[Clear tasks today]: Clear the calendar day

[Clear all]: Empty all the schedules

[Go to date]: Enter the dates you want to find, the cursor will jump to that date quickly

[Weekly]: the week / month display calendar.

[Calculator]: Can be continuously mixed arithmetic, the operation is simple, practical, and convenient

[Recorder]

[Audition]: hear the currently recording

[Record again]: re-recorded sound recordings of the current

[Delete]: Delete the current recordings

[Send]: Sound recordings sent by BT

[Record file list]; The memory card inside the recording file list

[STK]: Full name of the SIM card application toolkit (SIM Application Toolkit). It can provide you with flexible information functions, such as stock information, traffic information, weather and so on. STK functionality provided by the network operator decision. The business needs the support of SIM cards and network

[Torchlight]: Open or close torchlight.

Application

[Image browser]

[Change folder] Select a stored phone image folder storage space, this view picture

[Slide play] choose a slide show to view pictures

[Delete] Delete the currently selected image

[Set image as wallpaper]; The currently selected image as wallpaper

-
- [Rename]: the current rename the selected pictures
- [Mark]; tag for a single or multiple pictures, and then operate
- [Detail]: View the details of the selected pictures
- [Slide settings] Select the slide show effects and delay time
- [Game]:** Provide an interesting game
- [Ebook]:** View the “txt” document

File management

- 【MemoryCard】** : SD card needs to support T card
- [New folder]: Create a new folder.
- [delete]; delete the specified folder.
- [Details] View the folder or file for more information
- [Edit] the selected folder or rename the file or copy
- [Search] Enter the folder name to find out.
- [Sort] By the way you choose to sort the files.
- [mark] Select Mark / Unmark single / all

[More]

- ◆ Phone memort capacity;:View the phone's capacity
- ◆ Memory Card capacity: View the memory card capacity
- ◆ Format Phone; format phone memory
- ◆ Format memoryCard; Format memory card

Settings

【Call settings】

[Dual-SIM]

[Standby mode]: Dual SIM standby or standby only SIM1 or SIM2 only

[Reply by original SIM] Reply the call / send SMS / MMS by original SIM

*** This card is set back Call back function takes precedence over "the main and call card settings"**

[Set SIM name] SIM1 and SIM2 in the card slot to set the

display name

[**Call divert**]: transfer a call, respectively SIM1/SIM2

- ◆ Unconditional transfer: Set a forwarding number, for forwarding all calls are
- ◆ Divert if busy: set the forwarding number, transfer calls when in busy
- ◆ Divert if no answer: Set a forwarding number, in case of no response transfer
- ◆ Diverly if unreachable: to set the forwarding number in the phone unable to connect the case of transfer
- ◆ Cancel all diverts: cancel all of the transfer

[**Call barring**] respectively SIM1/SIM2 call for restrictions

[**Call waiting**] open call waiting, respectively SIM1/SIM2

[**Hide ID**] respectively SIM1/SIM to hide the machine when the power numbers.

* **SIM card, operators need to support**

[**Select line**] select lines respectively SIM1/SIM2

[**Fight mode**] Select the active flight mode

[**Others**]

[IP shortcut key] Select the start of the IP number SIM1 or SIM2

[50 sec voice call alert] Select the open or closed during a voice call has prompted every 50 seconds

[Vibration when connected] Select the phone is turned on or off the tone when

[Answer/Reject mode] Select whether to reject messages or return after any key answer

[Auto redial] Select whether to open automatically redial function

【Phone settings】

[Time & date]

- ◆ Set time: set the phone to display the time
- ◆ Set date: set the phone to display the date
- ◆ Time format: Set the display time format
- ◆ Date display type: Set the date display format

[Select language] Select phone display language. The unit provides both simplified Chinese and English languages.

[Shortcut settings] Set up and down arrow keys to quickly access the function menu

[Auto power on/off] Set the time and frequency of Automatic Turning

[Slide operation] Set the setting of Slide

[Power management] check the battery's current charge

[Restore factory settings] restore the factory settings

【Display settings】

[Wallpaper settings] Set wallpaper

[Idle screen style] Select the standby interface style as the basic style or smart style

[Idle display settings] Select whether the standby time / operator / day schedule / personal terms

[Contrast] adjust the screen's backlight brightness

[Backlight] Set the screen's backlight time

[Keypad light] Set the backlight time key

[Animation effect] Set the main menu, special effects / animation startup / shutdown animation / other.

【Security settings】

[PIN] Select open or modify the phone's PIN code

[PIN2] PIN2 choose to modify the phone code

[Privacy] set access to enter the password to view functionality. (Including: call log / messages / camera / address book / document management / e-book / calendar schedule / U disk)

The default password is: 1234

[Power-on password] Set the need to enter a password to open the boot function of the normal boot

The default password is: 1234

【Profile】

The phone offers a variety of patterns and make the default settings. When you insert the headset automatically goes into headset mode phone. Enter the conventional model, quiet, vibration mode, bass, treble several vibration

modes, you can enter the "Options / Settings " to set the following options

[**Activate**]: Activate the selected mode

[**Customize**]: set the selected mode

[Ring settings]

◆ SIM call ring: set the SIM card of the ringing tone

◆ SIM MSG ring; set the SIM card message tone

[Adjust volume]

◆ Caller ringtone: set the ringing tone volume

◆ Message ringtone: ring volume settings information

◆ Call volume: Set the volume of calls

◆ Alarm volume; set the alarm tone

◆ Power ring tone: the voice of setting switch

[Call alert] a ring, vibration, quiet, vibration and ringing and ringing after the first five vibration incoming call alert for you to choose

[Message alert] a ring, vibration, mute, ringing and message alert vibration four ways for you to choose

[Alarm&calendar remind] a ring, vibration, mute, ringing and

message alert vibration four ways for you to choose

[Key tone] set the key tone of voice

[Slide tone] Set the tone of slide

[Battery low alert] Set the tone of Battery low

[Power on/off tone]: Set the sound is turned off

[**Rename**] rename the selected mode