

# Basics


**Notes:** Before using this information and the product it supports, be sure to read the following:

- *Safety, Warranty & Quick Start Guide*
- *Regulatory Notice*
- "Important safety and handling information" in "Appendix".

The *Safety, Warranty & Quick Start Guide* and the *Regulatory Notice* have been uploaded to the website at <http://support.lenovo.com>.

## Home screen

The home screen is the starting point for using your device. For your convenience, the home screen is already set up with some useful apps and widgets.



*NOTE: Your device features and the home screen may be different depending on your location, language, carrier, and device model.*

You can customize your own home screen at any time.


- **Home screen**  
On the first home screen, there is a **Google** Search bar, a video widget and a **Lenovo Weather** widget. The other home screens contain apps.
- **Preview screen**

Tap and hold anywhere on the home screen except the icons.



At the top of the screen are preview images of the home screens.

At the bottom of the screen are widgets.

- **Add a home screen**

On the preview screen, slide the home screens to the left. When you see the last home screen, tap  to add a home screen.

- **Delete a home screen**

On the preview screen, tap  to hide the widgets, then tap  at the top right of the home screen that you want to delete.

- **Add a widget to a home screen**

On the preview screen, slide the widgets left or right, drag a widget to where you want to place it, and release it.


- **Change the wallpaper**


Go to **Settings > Display > Wallpaper** and choose the wallpaper that you like.

- **Move an app to another screen**

Tap and hold an app that you want to move, drag it to the left or right side of the screen, then release it where you want to place it.




- **Uninstall an app**


On a home screen, tap and hold an app, then drag it to the  and tap **Uninstall**.

*Note: If  is showing at the top of the screen, this means the app should not be uninstalled.*

## Screen buttons


There are three buttons at the bottom of the home screen.

- **Back button:** Tap  to return to the previous page.
- **Home button:** Tap  to return to the default home screen.
- **Recent button:** Tap  to see recent apps. Then you can do the following:
  - Tap an app to open it.
  - Drag an app upwards to create multi-windows.




## Notifications

Slide from the top left of the screen to see the notifications.



## Side switch

Slide from the top right of the screen to see the side switch.




## Smart side bar

### Setting the smart side bar

Go to **Settings** > **Smart Side Bar**, choose **Auto**, **Manual** or **Off**.

- **Auto**: Smart side bar appears at the left or right side when you rotate the screen. Sound and visual mode can switch automatically.
- **Manual**: You need to slide from the left or right side of the screen to use the smart side bar.
- **Off**: This feature is not available.

### Using the smart side bar




In the smart side bar, there are:

- **Apps:** such as video, photo, book apps and so on. Simply tap one to access it.
- **Settings:** You can go to Settings or configure the display settings manually, such as Standard, Multimedia, and Reading.






# Camera

To open the **Camera**, go to **Camera**.



## Taking photos and videos

You can take photos and record videos with your device's built-in camera.

- Tap  to take a photo.
- Tap  to record a video.
- Tap  to switch between the front and the back camera.
- Tap  to choose the **Capture mode**.
- Tap  to set the color effect.

- Tap  to configure the other camera settings.

## Taking screenshots

Press and hold the **On/Off** button and the **Volume down** button at the same time.

## Viewing pictures and videos

Photos and videos are stored in your device's internal storage. You can view your photos and videos by using the following methods:

- Tap the review button when using the **Camera** app.
- Go to **Gallery**.
- Go to **File Browser**.

The screenshots are stored in your device's internal storage. You can view the screenshots by using the following methods:

- Go to **Gallery**.
- Go to **File Browser**.



You need to set up a wireless network before connecting to the Internet.

### Setting up a **WLAN** network

Go to **Settings > WIRELESS & NETWORKS > WLAN**.

Turn on the WLAN block and tap one WLAN hotspot in the list, then you can connect to the Internet.

When you access a secure link, you need to input your login name and password to connect.

*NOTE: You need to have some valid WLAN hotspots to link to.*

### Setting up a **VPN** network

VPNs used within organizations allow you to communicate private information securely over a non-private network. You may need to configure a VPN, for example, to access your work email. Ask the network's administrator for the settings necessary to configure a VPN for your network. When one or more VPN settings are defined you can:

- Go to **Settings > WIRELESS & NETWORKS > More > VPN**.
- Tap **⊕** to edit the VPN profile, including the server name, the type and the server address, and then tap **Save**.
- Tap the VPN server name, input the username and password, and then tap **Connect** to connect to the VPN network.
- Tap and hold the VPN server name to edit or delete the VPN.





# Network

You need to set up a wireless network before connecting to the Internet.

- Set up a WLAN network
- Set up a mobile network
- Set up a VPN network

You can also share your mobile network with others.

- Set up a hotspot

## Setting up a WLAN network

Go to **Settings > WIRELESS & NETWORKS > WLAN**.

Turn on the WLAN block and tap a WLAN hotspot in the list to connect to the Internet.

When you access a secure link, you need to enter your login name and password to connect.

*NOTE: You need to have some valid WLAN hotspots to connect to.*

## Setting up a mobile network

Go to **Settings > WIRELESS & NETWORKS > SIM management**.

Turn on your carrier's service and then turn on the **Data connection**.

*NOTE: You need a valid SIM card with a data service. If you don't have a SIM card, contact your carrier.*

## Setting up a VPN network

VPNs used within organizations allow you to communicate private information securely over a non-private network. You may need to configure a VPN, for example, to access your work email. Ask the network's administrator for the settings necessary to configure a VPN for your network. When one or more VPN settings are defined you can:

- Go to **Settings > WIRELESS & NETWORKS > More > VPN**.
- Tap **+** to edit the VPN profile, including the server name, the type and the server address, and then tap **Save**.
- Tap the VPN server name, input the username and password, and then tap **Connect** to connect to the VPN network.
- Tap and hold the VPN server name to edit or delete the VPN.

## Setting up a hotspot

You can use **Personal hotspot** to share an Internet connection with a computer or other device.

Go to **Settings > WIRELESS & NETWORKS > More... > Tethering & portable hotspot** and do the following:


- Turn on the **Portable WLAN hotspot**.
- Tap **Set up WLAN hotspot** to configure the hotspot.

You can also use **Bluetooth tethering** and **USB tethering**.

*NOTE: Tell your friends the Network SSID and password, and then they can share your mobile network.*

# Internet

You can surf the Internet if your device has been connected to a wireless network.  
To open the **Browser** app, go to **Browser**.



## Visiting websites

You can use the **Browser** app to visit websites.

- **Type web address**  
You don't need to type the full web address of an "http://" website to access it.  
To visit "http://www.lenovo.com", simply type "www.lenovo.com" into the address bar and tap **Go**.
- **Search keywords**  
You can also type keywords into the address bar to search the webpages.  
You can set a search engine in **Settings > Advanced > Set search engine**.
- **Add a new webpage**  
Tap **+** to add a new webpage tab.  
Tap **⋮ > New incognito tab** to visit a website without leaving a trace.
- **Close a webpage**  
Tap **X** next to **+** to close a webpage tab.
- **Refresh a webpage**  
Tap **↺** to refresh a webpage.  
Tap **◀** to return to the previous webpage.  
Tap **▶** to go forward to a recent webpage.

## Saving webpages


You can save images and webpages in your device's internal storage.

- **Save images**  
Tap and hold the image, then tap **Save image**.
- **Save webpages**



Tap  > **Save for offline reading**.

- **Bookmark webpages**

Tap , then tap **OK** to add a webpage to Bookmark.


Tap , to view **Bookmarks**, **History** and **Saved pages**.

- **Set download directory**

Tap  > **Settings** > **Advanced** > **Set download directory** and change the download directory.

## Set accessibility

Tap **Settings** > **SYSTEM** > **Accessibility** to set the text scaling, the zoom on double-tap, the minimum font size, and so on.



You can receive and send emails if your device has been connected to a wireless network.

To access the **Email** app, go to **Email**.

To access the **Google Email** app, go to **Gmail**.

## Setting up an Email account

You can sign into Email if you have an email account. If not, you will need to create an email account.

You need to set up an email account the first time you use the **Email** app.

On the **Account setup** page, type your email address and password and tap **Next**.

## Using Email

After setting up an email account you can use the **Email** app to send and receive emails.

## Adding an Email account

You can add several email accounts.

Go to **Settings > ACCOUNTS > Add account**, then tap **Email**.




You need to select the following settings before you use **Google Maps**.


Go to **Settings > PERSONAL > Location access** and do the following:



- Enable location access for **Google** apps
- Turn on **GPS**
- Turn on **WLAN & mobile networks location**




## Finding a location

Type the address that you want to find, then tap .



You can also tap , then speak. When you're done, tap .




## Current location

Tap  to see your current location.


Tap **My location** to check what's nearby.

When you access a secure link, you need to input your login name and password to connect.

## Planning a route

Tap  and type in the "from" and "to" addresses... or just keep it as "My location".

Choose the travel mode, by car, by bus, or on foot, then tap **Go**.





# Communication

You can manage contacts with the **Contacts** app. You can create a contact, and import and export contacts.

## Creating a contact

Go to **Contacts**.

Tap  to create a contact.

Enter the contact information, such as "Name", "Mobile", "Home" and so on.

When you're done, tap **Save**.

*NOTE: You can add a device or an account contact.*

## Importing and exporting contacts

Go to **Contacts**.

Tap **Settings** > **Import/Export contacts**.

Select **Import from storage**, and tap **Next**.

Or select **Export to storage**, and tap **Next**.

Choose the contacts that you want to import/export, and tap **OK**.





# Communication


You can use your device to make a call, send a message, and manage contacts.

## Managing contacts

You can manage contacts with the **Contacts** app. You can create a contact, and import and export contacts.

### Creating a contact

Go to **Contacts**.

Tap  to add a contact.

Enter the contact information, such as "Name", "Mobile", "Home" and so on.

When you're done, tap **Save**.

*NOTE: You can add a device or an account contact.*

### Importing and exporting contacts

Go to **Contacts**.

Tap **Settings** > **Import/Export contacts**.


Select **Import from storage**, and tap **Next**.

Or select **Export to storage**, and tap **Next**.

Choose the contacts that you want to import, and tap **OK**.


## Making a call

Go to **Contacts**, choose a name, then tap the phone number to make the call.



## Sending a message

Tap **Messaging**, then tap  to write a new message.



*NOTE: Tap Settings to set Smart Call, Dialer Sound Effect, Mercury Keyboard, Speed Dial, Auto IP Settings and Call Settings.*




You can transfer data between your device and computer. Transfer music, pictures, videos, documents, Android application package (APK) files, and so on.

## Connecting your device and computer

Connect your device and computer with a data line.

If you slide the top left of the screen, you will see "**Connected as a media device**" in the notification bar.

Tap **Connected as a media device** for other options.



## Operating the computer

Follow these steps:

- Find the new disk on the device.
- Copy the files.

## Installing APK

Follow these steps:

- You need to set the device to allow installation of apps obtained from unknown sources. Go to **Settings > PERSONAL > Security**, select **Unknown sources** and tap **OK**.
- Copy the APK file from the computer to the device in "**Media device (MTP)**" mode.
- Open the apps category in the **File Browser**.





# Appendix

## Important safety and handling information

To avoid personal injury, property damage, or accidental damage to the product, read all of the information in this section before using the product. For additional tips to help you operate your device safely, go to: <http://www.lenovo.com/safety>.

### Handle your device with care

Do not drop, bend, or puncture your device; do not insert foreign objects into or place heavy objects on your device. Sensitive components inside might become damaged.

Your device screen is made of glass. The glass might break if the device is dropped on a hard surface, is the subject of a high impact, or is crushed by a heavy object. If the glass chips or cracks, do not touch the broken glass or attempt to remove it from the device. Stop using the device immediately and contact Lenovo technical support for repair, replacement, or disposal information.

When using your device, keep it away from hot or high-voltage environments, such as electric appliances, electric heating equipment, or electric cooking equipment. Use your device only in the temperature range of 0°C (32°F)—40°C (104°F)(storage -20°C (-4°F)—60 °C (140°F)) to avoid damage.

### Do not disassemble or modify your device

Your device is a sealed unit. There are no end-user serviceable parts inside. All internal repairs must be done by a Lenovo-authorized repair facility or a Lenovo-authorized technician. Attempting to open or modify your device will void the warranty.

### Built-in rechargeable battery notice

#### DANGER:

**Do not attempt to replace the internal rechargeable lithium ion battery. Contact Lenovo Support for factory replacement.**

### Plastic bag notice

#### DANGER:

**Plastic bags can be dangerous. Keep plastic bags away from babies and children to avoid danger of suffocation.**

### Adapter information

- **Prevent your device and ac adapter from getting wet.**

Do not immerse your device in water or leave your device in a location where it can get saturated with water or other liquids.

- **Use approved charging methods only.**

You can use any of the following charging methods to safely recharge the internal battery of your device:

Charging method	Display on	Display off
ac adapter	Supported, but the battery will charge slowly.	Supported
USB connection between the dc-in connector on the device and a USB connector on a personal computer or other device that comply with the USB 2.0 standards. Users have to	Supported, but will compensate power consumption and the battery will	Supported, but the battery will charge

use the connection to USB interfaces with USB 2.0 version or higher.	charge more slowly than usual.	slowly.
<b>Notes:</b> <ul style="list-style-type: none"> <li>• Display on: Device on</li> <li>• Display off: Device off or in screen lock mode</li> </ul>		

Charging devices might become warm during normal use. Ensure that you have adequate ventilation around the charging device. Unplug the charging device if any of the following occurs:

- The charging device has been exposed to rain, liquid, or excessive moisture.
- The charging device shows signs of physical damage.
- You want to clean the charging device.

**Warning:**

**Lenovo is not responsible for the performance or safety of products not manufactured or approved by Lenovo. Use only approved Lenovo ac adapters and batteries.**

**Prevent hearing damage**

Your device has a headphone connector. Always use the headphone connector for headphones (also called a headset) or earphones.

**CAUTION:**

**Excessive sound pressure from earphones and headphones can cause hearing loss. Adjustment of the equalizer to maximum increases the earphone and headphone output voltage and the sound pressure level. Therefore, to protect your hearing, adjust the equalizer to an appropriate level.**

Excessive use of headphones or earphones for a long period of time at high volume can be dangerous if the output of the headphone or earphone connectors do not comply with specifications of EN 50332-2.

The headphone output connector of your device complies with EN 50332-2 Sub clause 7. This specification limits the device's maximum wide band true RMS output voltage to 150 mV. To help protect against hearing loss, ensure that the headphones or earphones you use also comply with EN 50332-2 (Clause 7 limits) for a wide band characteristic voltage of 75 mV. Using headphones that do not comply with EN 50332-2 can be dangerous due to excessive sound pressure levels.

If your device came with headphones or earphones in the package, as a set, the combination of the headphones or earphones and the device already complies with the specifications of EN 50332-1. If different headphones or earphones are used, ensure that they comply with EN 50332-1 (Clause 6.5 Limitation Values). Using headphones that do not comply with EN 50332-1 can be dangerous due to excessive sound pressure levels.

- **Sound pressure warning statement**

For the device that is tested in accordance with EN 60950-1: 2006+A11:2009:+A1:2010+A12:2011, it is mandatory to perform audio tests for EN50332. This device has been tested to comply with the Sound Pressure Level requirement laid down in the applicable EN 50332-1 and/or EN 50332-2 standards. Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.

- **Warning statement**

**To prevent possible hearing damage, do not listen at high volume levels for a long period of time.**

**Take care when using your device in a motor vehicle or on a bicycle**

Always prioritize your safety and the safety of others. Follow the law. Local laws and regulations might govern how you can use mobile electronic devices, such as your device, while you drive a motor vehicle or ride a bicycle.

**Dispose according to local laws and regulations**

When your device reaches the end of its useful life, do not crush, incinerate, immerse in water, or dispose of your device in any manner contrary to local laws and regulations. Some internal parts contain substances that can explode, leak, or have an adverse environmental affect if disposed of incorrectly.

See "Recycling and environmental information" for additional information.

**Keep your device and accessories away from small children**

Your device contains small parts that can be a choking hazard to small children. Additionally, the glass screen can break or crack if dropped on or thrown against a hard surface.

## Protect your data and software

Do not delete unknown files or change the name of files or directories that were not created by you; otherwise, your device software might fail to work.

Be aware that accessing network resources can leave your device vulnerable to computer viruses, hackers, spyware, and other malicious activities that might damage your device, software, or data. It is your responsibility to ensure that you have adequate protection in the form of firewalls, antivirus software, and anti-spyware software and keep such software up to date.

Keep electrical appliances away from your device, such as an electric fan, a radio, high-powered speakers, an air conditioner, and a microwave oven. The strong magnetic fields generated by electrical appliances can damage the screen and the data on the device.

## Be aware of heat generated by your device

When your device is turned on or the battery is charging, some parts might become hot. The temperature that they reach depends on the amount of system activity and the battery charge level. Extended contact with your body, even through clothing, could cause discomfort or even a skin burn. Avoid keeping your hands, your lap, or any other part of your body in contact with a hot section of the device for any extended time.

## Polyvinyl Chloride (PVC) cable and cord notice

WARNING: Handling the cord on this product or cords associated with accessories sold with this product will expose you to lead, a chemical known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling.

## Electronic emission notices

### Federal Communications Commission (FCC) Declaration of Conformity

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an authorized dealer or service representative for help.

Lenovo is not responsible for any radio or television interference caused by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

Lenovo (United States) Incorporated

1009 Think Place - Building One

Morrisville, NC 27560

Telephone: 1-919-294-5900



### FCC Caution

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Industry Canada Class B emission compliance statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

### IC Caution



This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en

- **Industry Canada Class B Emission Compliance Statement**

This Class B digital apparatus complies with Canadian ICES-003.

- **Avis de conformité à la réglementation d'Industrie Canada**

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

### European Union-Compliance to the Electromagnetic Compatibility Directive

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. Lenovo cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the installation of option cards from other manufacturers.

This product has been tested and found to comply with the limits for Class B Information Technology Equipment according to European Standard EN 55022. The limits for Class B equipment were derived for typical residential environments to provide reasonable protection against interference with licensed communication devices.

**EU contact: Lenovo, Einsteinova 21, 851 01 Bratislava, Slovakia**



### German Class B compliance statement

#### Deutschsprachiger EU Hinweis:

Hinweis für Geräte der Klasse B EU-Richtlinie zur Elektromagnetischen Verträglichkeit Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG (früher 89/336/EWG) zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse B ein. Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der Lenovo empfohlene Kabel angeschlossen werden. Lenovo übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der Lenovo verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der Lenovo gesteckt/eingebaut werden.

#### Deutschland:

Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Betriebsmitteln Dieses Produkt entspricht dem „Gesetz über die elektromagnetische Verträglichkeit von Betriebsmitteln“ EMVG (früher „Gesetz über die elektromagnetische Verträglichkeit von Geräten“). Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG (früher 89/336/EWG) in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Betriebsmitteln, EMVG vom 20. Juli 2007 (früher Gesetz über die elektromagnetische Verträglichkeit von Geräten), bzw. der EMV EG Richtlinie 2004/108/EC (früher 89/336/EWG), für Geräte der Klasse B.

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen. Verantwortlich für die Konformitätserklärung nach Paragraf 5 des EMVG ist die Lenovo (Deutschland) GmbH, Gropiusplatz 10, D-70563 Stuttgart.

Informationen in Hinsicht EMVG Paragraf 4 Abs. (1) 4:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse B.

### Korea Class B compliance statement

B급 기기(가정용 방송통신기자재)

이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다

### Japanese VCCI Class B statement

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテ

レビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。 VCCI-B

Japan compliance statement for products which connect to the power mains with rated current less than or equal to 20 A per phase.

日本の定格電流が 20A/相 以下の機器に対する高調波電流規制  
高調波電流規格 JIS C 61000-3-2 適合品

## Environmental, recycling, and disposal information

### General recycling statement

Lenovo encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Lenovo offers a variety of programs and services to assist equipment owners in recycling their IT products. For information on recycling Lenovo products, go to: <http://www.lenovo.com/recycling>.

### General recycling statement



Country-specific information is available at <http://www.lenovo.com/recycling>.

### Turkish statement of compliance

The Lenovo product meets the requirements of the Republic of Turkey Directive on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (EEE).

Bu Lenovo ürünü, T.C. Çevre ve Orman Bakanlığı'nın "Elektrik ve Elektronik Eşyalarda Bazı Zararlı Maddelerin Kullanımının Sınırlandırılmasına Dair Yönetmelik (EEE)" direktiflerine uygundur. EEE Yönetmeliğine Uygundur.

### Declarações de Reciclagem no Brasil

Descarte de um Produto Lenovo Fora de Uso Equipamentos elétricos e eletrônicos não devem ser descartados em lixo comum, mas enviados à pontos de coleta, autorizados pelo fabricante do produto para que sejam encaminhados e processados por empresas especializadas no manuseio de resíduos industriais, devidamente certificadas pelos órgãos ambientais, de acordo com a legislação local. A Lenovo possui um canal específico para auxiliá-lo no descarte desses produtos. Caso você possua um produto Lenovo em situação de descarte, ligue para o nosso SAC ou encaminhe um e-mail para: [reciclar@lenovo.com](mailto:reciclar@lenovo.com), informando o modelo, número de série e cidade, a fim de enviarmos as instruções para o correto descarte do seu produto Lenovo.

### Recycling information for Japan

Recycling and disposal information for Japan is available at: <http://www.lenovo.com/recycling/japan>.

### Recycling information for India

Recycling and disposal information for India is available at:

[http://www.lenovo.com/social\\_responsibility/us/en/sustainability/ptb\\_india.html](http://www.lenovo.com/social_responsibility/us/en/sustainability/ptb_india.html).

### Battery recycling marks

- The battery recycling information of Taiwan



廢電池請回收

- Battery recycling information for the United States and Canada



US & Canada Only

- Battery recycling information for the European Union

EU



## Troubleshooting

### Insufficient memory prompt appears during app installation

Please free up some memory and try to install again.

### The touch screen does not work or is not sensitive

Please long-press the power key for over 10 seconds to restart.

### Cannot start or system crashed

Please charge the battery for half an hour and then long-press the power key for over 10 seconds to restart.

### Makes no sound when called or is not audible

Please adjust the volume using the volume keys.

### Cannot access the internet via wireless network

Restart the wireless router or go to Settings and restart Wlan.

### Cannot wakeup the tablet from sleep mode

Please long-press the power key to restart.