ALL RIGHTS RESERVED

Spice Retail Ltd ©2014. All rights are reserved. No part of this document can be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners. While all the efforts have been made to ensure the accuracy of contents in this manual, we presume no responsibility for errors or omissions or statements of any kind, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

We operate a policy of continuous development and reserve the right to make changes, modifications and improvements to the device, device features/specifications or any of its parts without prior notice. Your device may have preinstalled bookmarks and links for third party internet sites and may allow you to access third party sites. These are no affiliated with Spice, and Spice does not endorse or assume liability for them. If you access such sites, take precautions for security or content.

The limited warranty does not cover user manuals or any third party software, settings, content, data or links, whether included/ downloaded in the product, whether included during installment, assembly, shipping or any other time in the delivery chain or otherwise and in any way acquired by you.

To the extent permitted by applicable law(s), Spice does not warrant that any Spice software will meet your requirements, will work in combination with any hardware or software applications provided by a third party, that the operations of the software will be uninterrupted or error free or that any defects in the software are correctable or will be corrected.

User's Manual is provided just to guide the user about the functionality of the device. This does not seem to be any certificate of technology. Some functions may vary due to modifications and up-gradations of software or due to printing mistake.

SAFETY PRECAUTIONS

Please read the following safety guidelines before using the device.

- Do not use the phone while you are driving.
- Do not place magnetic storage media near your phone.
 Radiation from the phone may erase the information stored on them.
- Keep your phone and its accessories away from children.
- Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. People having active medical implants should keep their cell phone at least 15 cm away from the implant.
- Permanent hearing loss may occur if you use earphones or headphones at high volume.
- Use a wireless hands-free system (headphone/ headset) with a low power Bluetooth emitter.
- Make sure the cell phone has a low SAR.
- Keep your calls short or send a text message (SMS) instead. This advice applies specially to children adolescents and pregnant women.
- Use cell phone when the signal quality is good.

Notice:

- Do not dismantle the device or accessories otherwise, manufacturer is not liable to pay for damages as the device and accessories are not covered by warranty.
- Use only original batteries and charging devices.
- Please back up your important data timely and keep them properly. The company is not liable for any failure to call or

loss of data due to mis-operation, poor signal or power cut, etc.

- All the screens in this manual are for reference only, and some contents actually displayed may depend upon the presetting of the service provider or the network operator, or the SIM card. If any functions referred to in this manual are different from those of your device, please follow your device.
- Do not put use it in a place with flammable gas such as a petrol pumps. The temperature recommended for using the device is 5-35°C Do not touch the charger, power cable or socket with wet hands. This may cause an electric shock.

If your phone or any of its accessories do not function normally, then please visit your nearest authorized service facility. The qualified personnel will assist you, and if necessary, will arrange for the service.

SAR (Specific Absorption Rate)

Your device conforms to the Indian guidelines for exposure to radio waves. The limits are given in terms of a unit referred to as the Specific Absorption Rate (SAR), which is a measure of the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value as per the Indian guidelines standard is 1.6 Watts per kg (Watt/kg), averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of human tissue. The highest SAR value of this device when tested is **0.741 Watt/kg**.

TABLE OF CONTENTS

ALL RIGHTS RESERVED	
SAFETY PRECAUTIONS	
TABLE OF CONTENTS	
WHAT'S IN THE BOX?	
1. UNDERSTANDING YOUR DEVICE	
1.1 GENERAL INFO	
1.2 DEVICE OVERVIEW 2. GETTING STARTED	
2.1 INSTALLING CARDS & BATTERY	
2.2 POWERING ON/OFF THE DEVICE	
3. BASIC OPERATIONS	
3.1 CALLING	
3.3 CONTACTS	
3.5 FIREFOX	
4. HOME SCREEN	
5. MULTIMEDIA	
5.1 MUSIC PLAYER	
5.2 CAMERA	
5.3 VIDEO PLAYER	
5.4 GALLERY	
5.5 FM RADIO	
6. NETWORK	
6.1 WI-FI	
6.2 BLUETOOTH	
7. SETTINGS	
7.1 NETWORK & CONNECTIVITY	25
7.2 PERSONALIZATION	25
7.3 PRIVACY & SECURITY	25
7.4 STORAGE	25
7.5 DEVICE	
7.6 OPERATOR SERVICES	
7.6 OPERATOR SERVICES	26

10. S	SUPPORT AND CONTACT	. 31
9. SP	PECIFICATIONS	. 30
CC	ONNECTA2	29
	ACEBOOK	
YO	OU TUBE	28
MA	ARKETPLACE	27
CL	LOCK	27
CA	ALENDAR	27

WHAT'S IN THE BOX?

Your package comes with the following items. If any of these is missing, please contact your retailer

- Device
- ➤ USB Cable
- > Charger
- User's Manual
- Headset
- Battery
- Warranty Card
- Service Centre List
- Silicon Cover

1. UNDERSTANDING YOUR DEVICE

1.1 GENERAL INFO

This device is a multi SIM phone that encloses features, such as **Firefox OS, Wi-Fi, 1.3MP+VGA Camera etc.** This phone is provided with two SIM slots for two different SIM cards. The SIM card inserted in the slot1 is called Master SIM, and the other one in the slot2 is known as Slave SIM. You can select to operate SIMs as per your personal and professional needs.



1.2 DEVICE OVERVIEW



Position of Keys

1	Front housing	2	The Volume keys
3	Receiver	4	Touch pannel
5	Home key	6	Front camera
7	Power key	8	Back camera deco
9	Back camera	10	Battery cover
11	Flash light	12	Speaker
13	USB	14	Audio jack

2. GETTING STARTED

2.1 INSTALLING CARDS & BATTERY

Please switch off your device before inserting or removing the battery/SIM card or memory card.

Installing SIM Card and Battery

Your device is provided with two SIM slots for two different SIM cards. In order to install battery and SIM card in the device, please follow the steps mentioned below:

- > Remove the back cover of the device.
- ➤ Hold the device with the front facing downwards; pull the battery cover.
- > Insert the SIM cards in the device.
- > Attach the battery.
- > Push the battery cover until it clicks into place.

Installing Memory Card

Your device supports T-Flash card, which is a multimedia memory card used to multiply the memory of the device. The T-flash card is small and should be pulled out and installed carefully and prudently in order to avoid any kind of damage. Please follow the steps mentioned below to install the memory card in the device:

- > Switch off your device.
- > Remove the battery cover.
- > Slide the T-Flash card into the slot.
- > Attach the battery.
- > Push the battery cover until it clicks into place.

Charging the Battery

The device prompts a warning tone and message stating insufficient battery when the battery power is low.

Please follow the instructions mentioned below to charge your device:

- > Plug the connector of the charger into the jack of the device.
- > Plug the charger into a standard AC wall outlet.

Charging...... Fully Charged......

You must fully charge the battery before using the device for the first time. It is recommended to charge the battery for three hours before using the device for the first time.

2.2 POWERING ON/OFF THE DEVICE

Turning On the Device

After installing the SIM cards and charging the battery, you are now ready to turn on your device.

- > Long press and hold the Power Key to turn on the device.
- > The first screen that appears is known as the home/idle Screen.
- > Drag the lock icon sidewards to unlock the screen.
- ➤ If the screen turns off, then press the Power Key to turn on the display.

Turning Off the Device

- > Press and hold the Power Key for 3 seconds.
- > A pop-up window appears, select Power off.
- > Select "Power Off" to confirm.

3. BASIC OPERATIONS

3.1 CALLING

To Make Calls

To make a call, please follow the steps mentioned below:

- > From the home screen, tap on dialer
- > Enter the phone number using the on-screen keyboard.

Tap to erase a wrong number. Tap and hold it to erase the entire number.

> After entering phone number, tap



> To end the call, tap to end the call.



Manage other voice call features

During a call, please select:

- > to mute/unmute the microphone.
- > 1 : to open loud speaker.
- > is use the dial pad.

3.2 MESSAGING

Your device features, sending and receiving of SMS (Short Message Service) and MMS (Multimedia Message Service). From the home screen tap on Messages icon.

Creating a Message



- > In To field; enter the recipient's phone number.
- > Type message in the message field.
- > Tap "Send" to send the message.

Receiving and Managing Messages

When you send and receive messages to/from a contact, these messages are grouped as a message thread. A message thread looks like an exchanged conversation.

To reply to a text message

- > Select a message thread to open it.
- > Select "message" to enter your text.
- > Tap "Send" to send the message.

To forward a text message

- > Tap to view a message thread.
- > Press and hold a message to view the message options.
- > Select Forward.
- ➤ In the To field, enter the recipient's phone number.
- > Tap "Send" to send the message.

MULTIMEDIA MESSAGE

A Multimedia message or MMS can contain letters, an image, an audio or video file. To create and send a MMS, please follow the steps mentioned below:


- ➤ While drafting a message, tap ... on the right most corner and select Add subject.
- In the to field, enter the recipient's phone number or email address and enter the Subject.

3.3 CONTACTS

Contacts refer to the phonebook that lets you store names, phone numbers, e-mail addresses and other information. You can save information such as name, picture, phone numbers, e-mail addresses, etc for each contact listed in your Contacts menu.



To add a Contact



- > Tap "+" to create a New contact..
- > You can enter contact information such as name, phone number, email address etc.
- > Tap Done to save the contact.

To import/export contacts

- Go to contact and tap menu .
- > Select import to import contacts or export to export the contacts.

3.4 EMAIL

Your device allows you to compose, read and send emails.

Setting up an Email Account

- > Enter the Main Menu, tap Email.
- > Enter your Name, Email address and Password.
- > Tap Next. The device will automatically retrieve email settings.

3.5 FIREFOX

Firefox is a tool which enables you to access the Internet.

To open a web page

- Go to firefox
- > Tap the address bar.
- > Type the URL and select Go.



To scroll the page

- > Use finger gestures to scroll up or down.
- > To scroll left or right, tap and swipe your finger towards right/left.

4. HOME SCREEN

From Home screen, you can quickly access common features, view notifications of missed calls, received messages and check connection status.



5. MULTIMEDIA

Your device features various multimedia options, such as Music Player, Camera, FM Radio and Video Player.

5.1 MUSIC PLAYER

Use the Music player to play music files. The songs saved in your SD Card can be played using the Music Player of the device.



5.2 CAMERA

Your device is equipped with camera and camcorder, which enables you to capture photos and videos.

5.3 VIDEO PLAYER


You can view/play your videos stored on your SD Card through the Video Player.



5.4 GALLERY

You can view the captured images, recorded video clips, and downloaded images in the Gallery.

The picture folder and video folder will be displayed. Select to view the camera pictures or camera videos. The images or videos will be displayed in thumbnails.



5.5 FM RADIO

You can use your phone to listen to FM radio stations once the original Headset is plugged into the connector. Please press the side key to adjust music volume.

6. NETWORK

6.1 WI-FI

Connect to a wireless network to browse Internet.

- > Enter Main Menu and tap Settings.
- > Tap 'ON' to activate Wi-Fi.
- > Tap Wi-Fi > Network notification to start detecting networks. The available networks will then be listed.
- > Tap ADD NETWORK to add a connection.

Note:

- ➤ If the device before the connection is successful, the equipment information will be saved in the pop-up window selected connection, select forget to remove device information.
- ➤ If the device does not encrypt selected connection in the pop-up window to connect.
- ➤ If the device is encrypted, the pop-up window will appear, enter the password.
- ➤ Network connection is successful; the status bar icon appears Wi-Fi connection.

6.2 BLUETOOTH

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

- > Access Settings by entering the main menu
- ➤ Click Bluetooth to turn on Bluetooth
- > To make your device discoverable, select bluetooth settings and check discoverable.

7. SETTINGS

Select Settings to view and adjust the settings of your device. The Settings menu is categorized into: network & Connectivity, Personalization, Privacy & Security, Storage, Device and Operator Services

7.1 NETWORK & CONNECTIVITY

Access this sub menu to view/modify changes related to Geolocation, Wi-Fi, Call Settings, SIM Management, Message Settings, Bluetooth, Data etc.

7.2 PERSONALIZATION

SOUND: view/change the sound settings of call, messages, alarm etc. DISPLAY: With this function you can configure the display characteristics of the device including brightness, Auto-rotate screen, wallpaper etc. LANGUAGE & KEYBOARD: Use the Language & Keyboard settings to select the language for the text on your device and for configuring the onscreen keyboard, including words that you've added to its dictionary. DATE: You can select to set date, time and time zone using this sub-menu.

7.3 PRIVACY & SECURITY

You can protect your device from unauthorized users by setting a passcode. You can also enable/disable app permission and do not track.

7.4 STORAGE

View and manage the data storage of your device.

Turning on enable USB storage allows another device to access files of your phone via data cable. You can also view application and media storage by accessing this sub menu.

7.5 DEVICE

You can view system information Including System updates, Status, Battery use, Legal information, Model number, version and so on. Also you can check the battery status of the device by accessing this sub-menu.

7.6 OPERATOR SERVICES

This sub-menu enables you to manage operator services of your SIMs installed in the device.

8. APPLICATIONS & UTILITIES

For your entertainment purpose, your device is provided with several interesting games, applications and utilities. Please ensure that you have GPRS setting in your device to access the applications. Contact your operator for GPRS settings.

CALENDAR

This phone supports Calendar. You can view calendar or edit an event using it.


CLOCK

The clock function gives you an access to alarm clock.

- > Tap Application Tab to enter the Main Menu
- > Select Clock
- > Select from the various options available, such as Timer, Alarm or Stopwatch.

MARKETPLACE

Marketplace allows you to find and download applications and fun games for your device.



YOU TUBE

YouTube is an online video streaming service that allows you to view, search, and upload videos.

To start using YouTube

Tap the Application Tab to enter Main Menu > Select YouTube.

Videos are grouped into various categories. Tap a category to see the available videos for that category.

Select a video to play it.

FACEBOOK

Facebook is a very popular social networking site around the world giving people the power to share and make the world more open and connected. Millions of people use Facebook every day to keep up with friends, uploads an unlimited number of photos, share links and videos, and learn more about the people they meet. Please ensure that you have GPRS

settings in your device to open Facebook. Contact your operator for GPRS settings.

CONNECTA2

ConnectA2 is compatible with WhatsApp for your Firefox OS device, always available in background. Send instant messages to your contacts using ConnectA2 and/or WhatsApp. Send and receive messages, emoticons, pictures, videos and audios for free. Receive notifications of new messages, even when the app is closed.

9. SPECIFICATIONS

Screen	8.89cm	
Battery	1400mAh	
Dimensions	115.6X62X11.2mm	
Band	900/1800MHz	
Standby Time	120hours	
Maximum Talk Time	8hours	

^{*} The standby time and maximum talk time depend upon the network signals and settings.

10. SUPPORT AND CONTACT

- You can visit <u>www.si2imobility.com/spicemobiles</u> for additional information, downloads and services related to your Spice handset.
- For further assistance or queries, you can call on SPICE customer helpline number **011-42921000** or mail at **customercare@smobility.in** or **product@smobility.in**.

Note: After sales service of the device is confined to the country in which the purchasing is done.



ENVIRONMENTAL CONCERN

Help us save Our Environment...GO GREEN..!!

All our endeavors are directed towards providing environment friendly products to you. The materials used in our devices are recyclable and can be reused to make new products. We strive to make products that are safe for our consumers as well as the environment. Come join hands with us and make world a better place to live.

Preserve natural resources for future generations by recycling your phone. The phone contains some metals, when recycled properly; these can be put back into circulation, decreasing the need for new metal mining. Recycling reduces the need for raw materials, saves energy, helps mitigate Global Warming and reduces pollution, reduces waste products in landfills; therefore preserving natural resources for the future and saving the planet.

Follow some simple steps and contribute towards saving the planet.

DOs

Recycle your handset and its accessories.

To protect natural resources and to promote re-use of the material, kindly separate batteries from other type of waste.

DONTs

Do not dispose off your mobile and its battery in fire.

Do not dispose your mobile with the regular waste.

Do not over charge your handset. Remove the charger when battery is full.

Don't trash your phone, instead RECYCLE it



This logo signifies that this product and/or its consitituents should not be disposed off with other household waste.

Hazards of Improper handling, accidental breakage, damage and /or improper recycling of hazardous elements

If this product is improperly handled, broken or damaged or carelessly recycled or disposed off in the fire, can result in environmental and data security concerns, including the following:

Affect nearly every system in the human body and result in birth defects, brain, heart, liver, kidney and skeletal system damage. They will also significantly affect the nervous and reproductive systems of the human body;

When burned, create cancer-producing dioxins which are released into the air we breathe; If thrown in landfills, may leach into groundwater affecting your local community;

In warm climates, the oxidation of mercury in the environment can be accelerated, leading to the creation of oxidized Hg atoms that are known to be associated with ozone depletion; and Improper recycling additionally results in data security issues, as private electronic information remains on hard drive, if not properly removed before disposal.

How to Recycle

Please get your electronics products recycled only through authorized

recyclers, approved by Pollution Control Board. We provide facility of recycling of our products. For details of our collection centers, please visit our website or call our customer care. Help us to GO GREEN.

Constitution of Hazardous Elements in your Device:

Your device does not contain the following hazardous elements in a proportion higher than the limits provided hereunder: maximum concentration value of 0.1% by weight in homogenous materials for lead, mercury, hexavalent chromium, polybrominated biphenyls and polybrominated diphenyl ethers; and maximum concentration value of 0.01% by weight in homogenous materials for cadmium.