


ALL RIGHTS RESERVED

Spice Retail Ltd ©2015. All rights are reserved. No part of this document can be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners. While all the efforts have been made to ensure the accuracy of contents in this manual, we presume no responsibility for errors or omissions or statements of any kind, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

The limited warranty does not cover user manuals or any third party software, settings, content, data or links, whether included/ downloaded in the product, whether included during installment, assembly, shipping or any other time in the delivery chain or otherwise and in any way acquired by you.

To the extent permitted by applicable law(s), Spice does not warrant that any Spice software will meet your requirements, will work in combination with any hardware or software applications provided by a third party, that the operations of the software will be uninterrupted or error free or that any defects in the software are correctable or will be corrected.

 ***User's Manual is provided just to guide the user about the functionality of the device. This does not seem to be any certificate of technology. Some functions may vary due to modifications and up-gradations of software or due to printing mistake.***

SAFETY PRECAUTIONS

Please read the following safety guidelines before using the device.

- Do not use the phone while you are driving.
- Do not place magnetic storage media near your phone. Radiation from the phone may erase the information stored on them.
- Keep your phone and its accessories away from children.
- Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. People having active medical implants should keep their cell phone at least 15 cm away from the implant.
- Permanent hearing loss may occur if you use earphones or headphones at high volume.
- Use a wireless hands-free system (headphone/ headset) with a low power Bluetooth emitter.
- Make sure the cell phone has a low SAR.
- Keep your calls short or send a text message (SMS) instead. This advice applies specially to children adolescents and pregnant women.
- Use cell phone when the signal quality is good.

Notice:

- Do not dismantle the device or accessories otherwise, manufacturer is not liable to pay for damages as the device and accessories are not covered by warranty.
- Use only original batteries and charging devices.
- Please back up your important data timely and keep them properly. The company is not liable for any failure to call or loss of data due to miss-operation, poor signal or power cut, etc.
- All the screens in this manual are for reference only, and some contents actually displayed may depend upon the presetting of the service provider or the network operator, or the SIM card. If

any functions referred to in this manual are different from those of your device, please follow your device.

- Do not put use it in a place with flammable gas such as a petrol pumps. The temperature recommended for using the device is 5-35°C Do not touch the charger, power cable or socket with wet hands. This may cause an electric shock.



If your phone or any of its accessories do not function normally, then please visit your nearest authorized service facility. The qualified personnel will assist you, and if necessary, will arrange for the service.

SAR (Specific Absorption Rate)

Your device conforms to the Indian guidelines for exposure to radio waves. The limits are given in terms of a unit referred to as the Specific Absorption Rate (SAR), which is a measure of the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value as per the Indian guidelines standard is 1.6 Watts per kg (Watt/kg), averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of human tissue. The highest SAR value of this device when tested is **0.306 Watt/kg**.

TABLE OF CONTENTS

ALL RIGHTS RESERVED	1
SAFETY PRECAUTIONS	2
TABLE OF CONTENTS	4
1. UNDERSTANDING YOUR DEVICE	6
1.1 GENERAL INFO	6
1.2 DEVICE OVERVIEW	7
2. BASIC OPERATIONS	8
2.1 CALLING	8
2.2 MESSAGING	9
2.3 CONTACTS	10
3. HOME SCREEN	11
3.1 STATUS BAR	11
3.2 CUSTOMIZING SCREEN	11
4. MULTIMEDIA	14
4.1 MUSIC PLAYER	14
4.2 CAMERA	14
4.3 VIDEO PLAYER	14
4.4 GALLERY	14
4.5 FILE EXPLORER	14
4.6 SOUND RECORDER	15
4.7 FM RADIO	15
5. NETWORK	16
5.1 WI-FI	16
5.2 3G	16
5.3 BLUETOOTH	16
6. SETTINGS	17
6.1 WIRELESS & NETWORKS	17
6.2 AUDIO PROFILES	17
6.3 DISPLAY	17
6.4 STORAGE	17
6.5 BATTERY	17
6.6 APPS	18
6.7 LOCATION	18
6.8 SECURITY	18
6.9 LANGUAGE & INPUT	19
6.10 BACKUP & RESET	19
6.11 ACCOUNTS	19

6.12 DATE AND TIME	19
6.13 ACCESSIBILITY.....	19
6.14 ABOUT PHONE	19
7. APPLICATIONS & UTILITIES.....	20
GMAIL.....	20
PLAY STORE	20
PAYTM	20
SPICE ARENA.....	20
WHATSAPP DOWNLOAD	21
YOU TUBE	21
8. SPECIFICATIONS	22
9. SUPPORT AND CONTACT	23
ENVIRONMENTAL CONCERN	24

1. UNDERSTANDING YOUR DEVICE

1.1 GENERAL INFO

Spice Xlife-480Q is a multi SIM phone that encloses features, such as **4.5" FWVGA, 3G Smart Phone, 8GB ROM + 1GB RAM, 1750mAh Battery, Camera 5MP+1.3MP** etc. This phone is provided with two SIM slots. The SIM card inserted in the slot1 is called Master SIM, and the other one in the slot2 is known as Slave SIM. You can select to operate SIMs as per your personal and professional needs.



1.2 DEVICE OVERVIEW



Keys



Keys	Function
Power on/off key	Press and hold it, the phone will be switch on/off. Press it, the screen will be locked.
Volume key	Press it to increase or reduce the volume of receiver and speaker
Menu key	Touch it, show the menu option
Home key	Touch it , back to idle screen
Back key	Touch it ,return to the previous menu

2. BASIC OPERATIONS

2.1 CALLING


To Make Calls

On the start screen choose  and enter a complete phone number to make a call.



 Tap  to erase a wrong number. Tap and hold it to erase the entire number.

➤ After entering phone number, tap .




➤ To end the call, tap  to end the call.




Answer/Reject an Incoming Call


When you receive an incoming call, a notification message appears on the screen. In order to accept the call, drag  towards right. If you wish to reject the call, drag  towards left.

2.2 MESSAGING


Enter , and then press  to compose new message. You touch a text field where you want to enter text, to open the keyboard, click  to send.



2.3 CONTACTS

Tap  and enter Contacts and then add a contact (see figure below.)

Tap  to add a new contact to Phone or SIM card.



To import contacts

- Enter the Main Menu select People.
- Tap Menu > Import/export.
- Select to import contacts from Phone/ Internal storage/ SIM Card/ Memory Card.
- Select a particular source to import the contacts from.
- Select Next.
- Select the destination, such as Phone to copy contacts to.
- Select Next.
- Select "Select all" to import all contacts or mark the required contacts.
- Select OK.









3. HOME SCREEN

From Home screen, you can quickly access common features, view notifications of missed calls, received messages and check connection status.

Tap Application Drawer to access applications and settings of the device. The Application tab enables you to access the Main Menu and choose among the various utilities/ features available in the device.

3.1 STATUS BAR

The Status bar icons indicate different types of information. The table below lists various icons that might appear on the status bar of the device.

	Network intensity of SIM card 1 or SIM card 2
	Battery level of the device
	New message
	Missed call notification
	Wi-Fi connected
	USB connected
	Headset is plugged in
	Bluetooth is activated

3.2 CUSTOMIZING SCREEN

Add and Remove a Shortcut

In order to add a shortcut on the screen:

- Long press on the desired application to add on the screen.




Touch and hold an app to move or remove it!

➤ Long press on the application to move or Remove it.



Touch and hold an app to move or remove it!

Add Widgets to Home screen

Tap  on Home screen and then enter WIDGETS, Touch & hold to pick up a widget.

Setting the wallpaper

You can customize the wallpaper of your Home screen with default

wallpaper or with pictures taken from your device.

- In the idle mode, tap Menu Key > Wallpaper.
- Select your desired wallpaper from the various options




4. MULTIMEDIA

Your device features various multimedia options, such as Music Player, Camera, FM Radio and Video Player.

4.1 MUSIC PLAYER

Use the Music player to play music files. The songs saved in your SD Card can be played using the Music Player of the device.

- Tap  select Application tab
- Select Music

4.2 CAMERA

Your device is equipped with camera and camcorder, which enables you to capture photos and videos.

Capturing an Image

- Select Camera.
- Aim the phone at the subject, and then tap to take the shot.

4.3 VIDEO PLAYER

You can view/play your videos stored on your SD Card through the Video Player.

Tap  select Video player to play videos on the memory card.

4.4 GALLERY

You can view the captured images, recorded video clips, and downloaded images in the Gallery.


The picture folder and video folder will be displayed. Select to view the camera pictures or camera videos. The images or videos will be displayed in thumbnails.

4.5 FILE EXPLORER




You can browse, open and manage the data saved in the Device and Memory card by accessing this sub-menu. The device provides a certain

space for users to manage files and supports the T-Flash card. You can use the file browser to conveniently manage various directories and files on the T-Flash card.

4.6 SOUND RECORDER

You can use the sound recorder to record sounds and also select to save the recordings in your phone. Tap  select Application tab > Sound Recorder. When in the sound recorder interface, press menu key to select recording mode.

4.7 FM RADIO

You can use your phone to listen to FM radio stations once the original Headset is plugged into the connector. Please press the side key to adjust music volume. Tap  to stop the FM radio. Tap the ( ) to search the channels.

5. NETWORK

5.1 WI-FI

Connect to a wireless network to browse Internet.

- Enter Settings menu then tap 'ON' to activate Wi-Fi. .
- Tap Wi-Fi > Network notification to start detecting networks. The available networks will then be listed.
- Select your wireless network to connect If the device does not encrypt
- If the device is encrypted, the pop-up window will appear, enter the password.
- If the device before the connection is successful, the equipment information will be saved in the pop-up window select forget to remove device information.

5.2 3G

The device supports WCDMA protocol. Please make sure the 3G SIM card is inserted to your device.

Settings > Wireless & Networks > More > Mobile networks > Preferred network type>Auto

5.3 BLUETOOTH

Search the device and accept/transfer data. The received data is automatically stored in the directory.

- Enter Main Menu and tap Settings
- Tap 'ON' to activate Bluetooth
- Tap "Spice Mi-480Q" to make your device visible

6. SETTINGS

Select Settings to view and adjust the settings of your device. The Settings menu is categorized into: Wireless & networks, Device, Personal, Accounts and System.

6.1 WIRELESS & NETWORKS

Access this sub-menu to change/view the Wi-Fi, Bluetooth, Mobile Networks and VPN settings. Please refer to network section for detailed information on Wi-Fi and bluetooth.

6.2 AUDIO PROFILES

Your device provides four pre-defined user profiles that allow the operations of the device to best suit the environment you are in. The profiles are General, Silent, Vibration and Outdoor.

6.3 DISPLAY

With this function you can configure the display characteristics of the device including brightness, Auto-rotate screen, etc.

6.4 STORAGE

View and manage the data storage of your device:

Total Space and Available Space: Lists the amount of space on the micro SD card installed in your device and the amount you have used to store photos, videos, music, and other files.

Un-mount SD Card: Un-mounts the micro SD card from your device so that you can format the card or safely remove it when the device is on.

Available Space: The amount of internal phone storage used by the operating system, its components, applications (including those you downloaded), and their permanent and temporary data.

6.5 BATTERY

You can check the battery status of the device by accessing this sub-menu.

6.6 APPS

This sub-menu enables you to manage all the installed, running and applications saved in the device memory and SD card. You can remove and manage installed applications, view and control running applications, allow installation of non-Spice build in market applications.

6.7 LOCATION

Your device supports Global Positioning System. The settings related to the location can be configured using this sub-menu.

6.8 SECURITY

You can protect your device from unauthorized users by setting the PIN code or entering a password.

Enable or Disable SIM card PIN

When PIN code is enabled, you are required to enter the PIN code before making a call.

- Go to Application Drawer > Settings > Security.
- On the SIM card lock tab, select Set up SIM card lock.
- Select a SIM card.
- Tap Lock SIM card to use PIN. Check to enable, uncheck to disable.
- Enter the current PIN code.
- To change the PIN code, select Change PIN.
- Enter the old PIN code.
- Enter the new PIN code and confirm.

Setup Screen Lock

You can set up a lock for your screen in form of Pattern, PIN code or password.

- Go to Settings > Security
- Set up screen lock
- Select a desired form (Slide, Pattern, PIN code or password)

6.9 LANGUAGE & INPUT

Use the Language & Keyboard settings to select the language for the text on your device and for configuring the onscreen keyboard, including words that you've added to its dictionary.

6.10 BACKUP & RESET

You can use the Privacy settings to manage your personal information, such as backup of the data, automatic restore and factory data reset.

6.11 ACCOUNTS

Use the Accounts & Sync to add, remove, and manage your Google and other supported accounts. You also use these settings to control how and whether all applications send, receive, and sync data on their own schedules, and whether all applications can synchronize user data automatically.

6.12 DATE AND TIME

You can select to set date, time and time zone using this sub-menu.
Use Automatic unless you need to override the network values.
Use 24-hour format: Select to set 24-hour formats on or off.
Select Date format: Select from a variety of formats.

6.13 ACCESSIBILITY

You can use the Accessibility settings to configure any accessibility plug-ins you have installed on your device.

6.14 ABOUT PHONE

You can view system information Including System updates, Status, Legal information, Model number, Android version and so on.

7. APPLICATIONS & UTILITIES

Please ensure that you have GPRS setting in your device to access the applications. Contact your operator for GPRS settings.

GMAIL

Gmail is Google's web-based email service. Google Mail is configured when you first set up your device. Depending on your synchronization settings, Google Mail on your device is automatically synchronized with your Google Mail account on the web.

Go to Main Menu > Gmail.

Select Create or Sign in your Google account.

Follow the on screen instructions to login or create your Gmail username and password.

Once logged in, you can begin reading and sending emails from your Gmail account.

PLAY STORE

Play store allows you to find and download applications and fun games for your device.

- Go to Play Store and setup your Google account.
- Select Create to create a new account or Sign in to sign in your existing account.

Once you are signed in you can begin searching and downloading programs from the market. Tap Apps to view the list of applications available and tap Games to view the list of games available.

PAYTM

Paytm is India's largest mobile commerce platform. Paytm started by offering mobile recharge and utility bill payments and today it offers a full marketplace to consumers on its mobile apps.

SPICE ARENA

Spice Arena provides links to websites and content of third parties as service to those interested in this information. You can find apps, deals and fun with this application.

WHATSAPP DOWNLOAD

Access the menu to download the WhatsApp directly. Download the application and enjoy chatting with your friends and colleagues over network. This messenger is a smartphone messenger which allows you to enjoy unlimited conversations. Download the latest version of WhatsApp by clicking the WhatsApp Downloader and chat with your friends anytime anywhere. It is a third party network based application; please contact your operator.

YOU TUBE

YouTube is an online video streaming service that allows you to view, search, and upload videos.

To start using YouTube

Tap the Application Tab to enter Main Menu > Select YouTube.

Videos are grouped into various categories. Tap a category to see the available videos for that category.

Select a video to play it.

8. SPECIFICATIONS

Screen	4.5" FWVGA
Battery	1750mAh
Dimensions	133.5*68.5*9.4mm
Band	GSM900/1800, WCDMA2100
Standby Time	200 hours
Maximum Talk Time	7 hours
Power Adapter	5V / 500mA

** The standby time and maximum talk time depend upon the network signals and settings.*

9. SUPPORT AND CONTACT

- You can visit www.si2imobility.com/spicemobiles for additional information, downloads and services related to your Spice handset.
- For further assistance or queries, you can call on SPICE customer helpline number **1860 200 1003** or mail at customercare@smobility.in or product@smobility.in.

Note: After sales service of the device is confined to the country in which the purchasing is done.



ENVIRONMENTAL CONCERN

Help us save Our Environment...GO GREEN...!!

All our endeavors are directed towards providing environment friendly products to you. The materials used in our devices are recyclable and can be reused to make new products. We strive to make products that are safe for our consumers as well as the environment. Come join hands with us and make world a better place to live.

Preserve natural resources for future generations by recycling your phone. The phone contains some metals, when recycled properly; these can be put back into circulation, decreasing the need for new metal mining. Recycling reduces the need for raw materials, saves energy, helps mitigate Global Warming and reduces pollution, reduces waste products in landfills; therefore preserving natural resources for the future and saving the planet.

Follow some simple steps and contribute towards saving the planet.

DOs

Recycle your handset and its accessories.

To protect natural resources and to promote re-use of the material, kindly separate batteries from other type of waste.

DON'Ts

Do not dispose off your mobile and its battery in fire.

Do not dispose your mobile with the regular waste.

Do not over charge your handset. Remove the charger when battery is full.

Don't trash your phone, instead RECYCLE it



This logo signifies that this product and/or its constituents should not be disposed off with other household waste.

Hazards of Improper handling, accidental breakage, damage and /or improper recycling of hazardous elements

If this product is improperly handled, broken or damaged or carelessly recycled or disposed off in the fire, can result in environmental and data security concerns, including the following:

Affect nearly every system in the human body and result in birth defects, brain, heart, liver, kidney and skeletal system damage. They will also significantly affect the nervous and reproductive systems of the human body;

When burned, create cancer-producing dioxins which are released into the air we breathe; if thrown in landfills, may leach into groundwater affecting your local community;

In warm climates, the oxidation of mercury in the environment can be accelerated, leading to the creation of oxidized Hg atoms that are known to be associated with ozone depletion; and Improper recycling additionally results in data security issues, as private electronic information remains on hard drive, if not properly removed before disposal.

How to Recycle

Please get your electronics products recycled only through authorized recyclers, approved by Pollution Control Board. We provide facility of recycling of our products. For details of our collection centers, please visit our website or call our customer care. Help us to GO GREEN.

Constitution of Hazardous Elements in your Device:

Your device does not contain the following hazardous elements in a proportion higher than the limits provided hereunder: maximum concentration value of 0.1% by weight in homogenous materials for lead, mercury, hexavalent chromium, polybrominated biphenyls and polybrominated diphenyl ethers; and maximum concentration value of 0.01% by weight in homogenous materials for cadmium.