

# Read the following contents carefully before using your phone

## **Charge the battery**

Your battery has not charged at the factory. Never take out the battery when charging, because it might destroy your phone.

You can only use charger and USB data cable attached in package.

## **Choose appropriate tariff scheme**

When you use your phone, it may consume mass of Network data traffic. We strongly recommended you to consult to operator tariff scheme before using your phone.

## **Learn about Privacy Act**

Some countries has set strict regulations for phone calls recording method and timing. So we suggest you that it' s a better way to learn about related laws of the country before using phone recording.




## Setting Your Phone

When you power on your phone at the first time, please add a Company Account by "Setting"--"Account and Synchronization" to synchronize Emails, Calendar and Contacts. Please be sure to log in your Google Account so that you can use some Google Applications such as Gmail and Android Market and so on.


# Home Screen

You can change wallpapers , add practical Widgets to home screen and set application Shortcuts lightly for your phone.



Touch Home screen and hold, then accession option window will be displayed.



Home Screen personalization

There are five apps. for customization which can be switched by sliding your fingers left and right. Touch and hold  to display the whole five apps. It can be displayed on screen when you select one of them.

Touch and hold in blank on home screen , various of individualization widgets will pop-up on the screen.



Connect to Network

You can connect to network through data connection or Wi-Fi.

### **Data connection**

When you power on your phone at the first time (you should insert SIM card to SIM1 slot ), it will connect data service of operator automatically. If you insert both two SIM cards, data connection default will be on SIM1.

### **Wi-Fi**

1. Press **Menu** in lower left of home screen interface.
2. Select **settings > Wireless&Network**.
3. Select Wi-Fi to turn on Wi-Fi.



4. Select **Wi-Fi settings**, and then choose the available Wi-Fi network.

## **Contacts**

If you have added and logged in your Account, Contacts App. Will also display contacts in your account.

Even though there are many contacts in your SIM card, you just need one step to import all contacts to your phone.


1. On home screen, select **Contacts** .

2. Touch **Menu**, click **More>Import/Export>import contacts from SIM Card/SD card**.


If you have logged in exchange account, please select the account of the contact person you will import.

3. Touch **menu**, then select **Import ALL**.


Add contacts:

1. On home screen, select **Contacts** .
2. Touch **menu**, select **New contact**, then input contact information in related field.
3. After finishing inputting, select **Done** to save contact.

## E-Mail

If you have logged in your account, you can receive and send E-mails directly by selecting **Gmail**  on home screen.

You also can set and manage other E-mail account such as POP3, IMAP or Exchange by using E-mail Application.

1. On home screen, select **E-mail** .
2. After inputting Email Address and password, select **Manual setup** to choose the type of Email account.

If it does not display the menu, please select **Menu>Account** and touch **Menu> Add Account**, and then choose type of Email account after input Email address and password.

3. Follow instructions on screen, and finish Email account setting.




➤ You can check all Email account at the same site instead of switching in different Email account through Email application.

## Messaging

You can compose messages of SMS and MMS by using **Messaging** to keep in touch with important persons in your life.


On home screen, select **Messaging** , all sent and received messages will be classified orderly as contact name and phone number to all opened

messaging folders.




contacts classified interface

messages reciprocation interface

- Slip on the screen quickly to swipe dialogue list up and down.
- Choose contact name or phone number to look into messages reciprocation.
- Type message in the Type to compose field, then select **send**  in right side to send messages.

## Call Function

### Dialing Mode

You can make a call from dialing interface, besides, you can also make a call with number from text messages or Emails you choose or select contact person from Contacts, and select dial key  to make a phone



call.

- Most of the SIM card have been setted a PIN code by operator. Please input PIN CODE then click Done when requested. If input wrong PIN code three times in succession, SIM card will be locked immediately. Don't worry! You can ask for operator to search out your PUK code (PIN code unlock key).

You can protect your phone from unauthorized users by setting the PIN code or entering a password.

### **Enable or Disable SIM card PIN**

When PIN code is enabled, you are required to enter the PIN code before making a call.

- a) Go to Application Drawer > Settings > Location & Security.
- b) On the SIM card lock tab, select Set up SIM card lock.
- c) Tap Lock SIM card to use PIN to use the phone. Check to enable, uncheck to disable.
- d) Enter the current PIN code.
- e) To change the PIN code, select Change PIN.
- f) Enter the old PIN code.
- g) Enter the new PIN code and confirm.








### **Setup Screen Lock**

You can set up a lock for your screen in form of Pattern, PIN code or

password.

- a) Go to Settings > Location & Security
- b) Set up screen lock
- c) Select a desired form (Pattern, PIN code or password)


### **Make a call from dialing interface**

1. Touch  on Home screen to enter dialing interface.
2. Input a couple of numbers on dialing keypad, available numbers and contact list will be displayed on the interface.
  - If input a wrong number, please click  to erase. Hold  to erase all numbers.
3. Click  to close keypad and check if there are more available contacts or numbers.
  - 4. Slip on the list up and down slowly to look through screening list .
5. Please choose any method in the following to make a call:
  - Click phone numbers in contact list or click  after contact name.
  - Click  after input right number.
- During communicating or dialing time, calling status  will be displayed on screen.

# Camera

You can use camera to capture camera photos and videos to record journey when you are on a business trip or have a travel.

Attention: please ensure that you have insert memory card before using, because all pictures and videos will be saved in memory card. Access the

main menu and select Camera  to capture images.

There are two camera modes in the following:





image mode





camcorder mode



- switch between camera and camcorder
- storage place
- white balance adjusting
- Take a picture
- video quality option
- setting
- take a video record

### Take pictures

1. Enter image mode.
2. Setting picture size and quality.
3. Setting white balance.
4. Press  to take a picture.





### DV-recording


1. Enter camera mode, drag  to switch to camcorder mode.

2. Setting video quality and other settings such as white balance and color tone and so on.

3. Aim at your target with viewfinder.

4. Press  to start recording. Recorded time will be displayed on lower left quarter of the screen.

5. Press  to end record.






## FM Radio



You can listen in to broadcasts you like in any time and any place with FM.

➤ Please insert a headset before start FM, because the headset is necessary to serve as antenna.

1. Insert the headset attached active the radio.

with phone , and select  to

2. Click  and  to search radio station forward and backward automatically.

3. Click  and  to make fine-tuning for current frequency and the amplitude-frequency is 0.1MHz


4. Click the numbers displayed on lower part of the screen to save current frequency.

5. Select one of saved radio station to switch to the selected station.

6. Click Menu>settings in FM interface to set audio mode:stereo or mono;Also you can choose loudspeaker or headset to play.

7. Press side volume key to adjust the radio volume.

8. Click back key on bottom of screen to exit FM.


9. Click  to back to home screen and make FM play in backstage.



# BT

## Turn on and turn off BT

1. Access Settings by entering the main menu>**settings**>**Wireless & networks**.
2. Turn on or turn off BT.

- If you want to turn on and turn off BT easily, access Settings by entering the main menu>**Notifications**>click .

## Change device name

Device name can make other BT device identify your phone.

1. Press menu key>**settings**>**Wireless & networks**.
2. Select **BT settings**(Please turn on BT)
3. Select **Device name**.


4. Input device name you want, then click **OK**.

### **Connect BT headset**

You can listen to music and make calls through BT earphone.

- Your BT earphone have to support A2DP when listen to music and make calls.
- You have to make your BT earphone discoverable before connect it. So that your phone can search the earphone. Please reference earphone user manual to learn about how to set.

1. Access Settings by entering the main menu>**settings**>**Wireless & networks**.
2. Select **BT settings** (Please turn on BT)
3. Ensure to make device discoverable.
4. Click **Scan for devices**, your phone will start scanning BT devices in available range.
5. Select your earphone name when it display, then your phone will try to match your earphone.
6. If match failed, please input match password.

- When BT earphone connected to your phone, the icon  will be



displayed on status bar. you can listen to music and make calls with your BT earphone.

## Send documents through BT

You can send data to other phones or devices which have BT function.

1. You can send the following types of data:

- images and videos
- music
- contacts


2. Steps to send data:

- Photos: after capturing pictures, click  when preview.
- Pictures or videos: 1. Click  on home screen, select **images & videos**.

2. Touch and hold image you want to send, click **share**.

3. Select BT.

- Music : In music player interface, select

menu>  >BT

- Contact: 1. Touch and hold the contact in Contacts interface, select **share**.
- 2. In Contacts interface, select **menu>More>BT to choose contacts**.
- 3. When system advise you to turn on BT, please turn on it with instructions.
- 4. If you did not match receiving device, please select **Scan for devices**.
- 5. Select receiving device name.
- 6. Accept match application between sending device and receiving device when pop-up instruction.
- 7. (Receiving documents in receiving device (there has to be a memory card in receiving device)).

## Map and location

### Location settings

You have to enable unknown source before search locations on your phone.

1. On home screen, click menu key>**settings>location and safety**
2. Select one or two options of the following:



Through Wi-Fi: You can use Wi-Fi or GPRS to search approximate location.

Through GPS: search accurate GPS location. But it may consume more power and can only be used in clear atmosphere.

## Google map

With Google map, you can track your current location, check current traffic condition and particular direction of your destination.

- Only when you activate GPRS or Wi-Fi, you can use Google map.
- If you will use Google map to find a location, you have to activate GPS positioning.
- Google map is not cover all countries and cities.

Open Google map, select  to display your current location which mark by  in blue.

# Settings

You can customize all settings in **Settings** option. On home screen, select **Menu>Settings**.

- **Wireless & network:** Set Wi-Fi, data connectivity and BT and so on. Switches between two SIM cards and Fly mode.
  
- **Calling:** Set services such as call, call divert and so on.
  
- **Voice commands:** Set ring tone and adjust volume and so on.
  
- **Display:** Display settings, autorotation, luminance and so on.
  
- **Location and safety:** GPS settings, screen auto lock and PIN code setting.
  
- **Applications:** Manage your applications. stop and uninstall ans so on.
  
- **Account and synchronization:** Log in your Google account and Exchange account.

Manage synchronization and other settings of account.

- **Right of privacy:** Select some settings for back-up and restore factory default.

- **SD card and memory:** Check the internal storage space and memory card available space.

To remove the memory card from the phone, be sure to uninstall memory card on this screen.

- **Language and keyboard:** Set the system language, as well as manage your installed input methods.

- **Voice input and output:** Setting the voice input language.

If you have install text to speech application then you can use this option to set text to speech.

- **Accessibility:** These settings are available only if you have installed the application of auxiliary functions.

- **Date and time:** Set the date, time, time zone and date or time format.

- **Touch Calibration:** To make touch screen calibration
  
- **About phone:** Check the phone information, such as: type, version, battery and so on.