

What's in the Box

1

Your phone box contains the following items:

- Mobile phone
- Battery
- Charger
- USB cable
- Headset
- Quick start guide
- Safty information


For more information about how to use your phone, refer to the User Guide on the phone.

To read the User Guide, do as follows:

1. Connect your phone to a PC.
2. On the PC, choose **Start > My Computer**.
3. Double-click the Huawei logo, and then select **User Guide**.

Getting to Know Your Phone


2




Before Getting Started

3


Installing the SIM Card



Installing the microSD Card




Installing the Battery



Charging the Battery

4

Before charging the battery, make sure that the battery has been properly inserted into your mobile phone.



- 1 Connect your USB cable to your mobile phone, as shown in a.
- 2 Connect the other end of the cable to the charger, as shown in b.
- 3 Plug the charger into a power socket.

The phone starts charging, with the charging icon displayed in animation on the screen.

Setting up Your Phone

5


Powering On or Off Your Phone

- Press **⓪** to power on your phone.
- Press and hold **⓪** to open the Phone options menu. Then touch Power off > OK to power off.

Setting up Your Phone

The first time you power on your mobile phone, the phone displays a setup wizard to instruct you to set the phone, including:


- Using the onscreen keyboard
- Setting up your accounts
- Other important settings



Your Canvas Screen

6

Canvas Screen View



Locking the Screen

- When your mobile phone is on, press **⓪** to lock the screen.
- If you leave your phone idle for a while, the screen will lock automatically.

Unlocking the Screen

Press the **⓪**, **MENU** or **↶** to wake up the screen. Then unlock it by doing any of the following:


- Press the **MENU** to unlock the screen.
- Drag the lock icon from left to right to unlock the screen.

Expand the Canvas

7

The Canvas is a desktop which you can freely define and expand. You can do the following things on the Canvas desktop:

- Expand your screen display in any direction.
- Customize the Home screen.
- Create and arrange shortcuts.
- Create and arrange widgets.
- Create and arrange folders.
- Define and switch between wallpapers.




Widgets

8

A widget works as a shortcut to let you preview or use an application.

You can stick widgets on your desktop as icons or preview windows.


Besides the default widgets installed on your phone, you can also download more from Android Market.



Calling

9


Dialer

Touch  > Dialer to display the dialer.

Touch to switch among Dialer, Call log, Contacts, and Favorites.

Touch and hold to enter +.

Touch to make a voicemail.




Displays the number you enter.

Touch to browse all the matching contacts.



Touch to dial.

Touch to erase numbers.



Answering or Rejecting an Incoming Call



Answering:

- Press  to answer the call.
- Drag  to the right.


Rejecting:

- Press  to reject a call.
- Drag  to the left.

Entering Text

10

Using the Onscreen Keyboard

- On the Canvas screen, press and hold the **MENU** to show the keyboard.
- Touch the space where you write text to show the keyboard.
- Press  to hide the keyboard.

Switching the Input Method

Touch and hold the space where you write your text until the **Edit text** menu is displayed. Touch **Input Method**.





Switching TouchPal Keyboard Layout



Google Services

11

Google provides you various excellent services, such as Talk, Gmail, Market, and Maps.




Personalizing Your Phone

12

Changing the Wallpaper

On the Canvas screen, press **MENU**, and then touch **Wallpaper**. In the options menu, select a picture application. Select the wallpaper you want to use.




Changing the Ringtone

On the Canvas screen, press **MENU**, and then choose **Settings > Sound & display > Phone ringtone**. Select the ringtone in the list and then touch **OK**.



Changing the theme

On the Home screen, press **MENU**, and then choose **Themes**. Select the theme you want to use.



Important Safety Information

13

Operating Environment

- The device complies with the RF specifications when the device is used near your ear or at a distance of 1.5 cm from your body. Ensure that the device accessories such as a device case and a device holster are not composed of metal components. Keep your device 1.5 cm away from your body to meet the requirement earlier mentioned.
- Keep the ambient temperature between -10°C and 45°C while the device is being charged. Keep the ambient temperature between -10°C to 45°C for using the device powered by a battery.

Certification Information (SAR)

This device meets guidelines for exposure to radio waves. Your device is a low-power radio transmitter and receiver. As recommended by international guidelines, the device is designed not to exceed the limits for exposure to radio waves. These guidelines were developed by the independent scientific organization International Commission on Non-ionizing Radiation Protection (ICNIRP) and include safety measures designed to ensure safety for all users, regardless of age and health.

The Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the

body when using a device. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the device when being operated can be well below the value. This is because the device is designed to use the minimum power required to reach the network.

The SAR limit also adopted by Europe is 2.0 W/kg averaged over 10 grams of tissue. The highest SAR value for this device type when tested at the ear is 0.717 W/kg.

Disposal and Recycling Information



This symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage. Do not dispose of your device or batteries as unsorted municipal waste. The device (and any batteries) should be handed over to a certified collection point for recycling or proper disposal at the end of their life. For more detailed information about the recycling of the device or batteries, contact your local city office, the household waste disposal service, or the retail store where you purchased this device. The disposal of this device is subject to the Waste from Electrical and Electronic Equipment (WEEE) directive of the European Union. The reason for separating WEEE and batteries from other waste is to minimize the potential environmental impacts on human health of any hazardous substances that may be present.

Reduction of Hazardous Substances

This device is compliant with the EU Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH) Regulation (Regulation No 1907/2006/EC of the European Parliament and of the Council) and the EU Restriction of Hazardous Substances (RoHS) Directive (Directive 2002/95/EC of the European Parliament and of the Council). For more information about the REACH compliance of the device, visit the Web site www.huaweidevice.com/certification. You are recommended to visit the Web site regularly for up-to-date information.

EU Regulatory Conformance

CE 0682 

Hereby, Huawei Technologies Co., Ltd. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For the declaration of conformity, visit the Web site www.huaweidevice.com/certification.

Note: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU).

Note: This device may be operated in all member states of the EU.

France: Outdoor use limited to 10 mW e.i.r.p. within the band 2454-2483.5 MHz.

Italy: For private use, a general authorisation is required if WAS/RLAN's are used outside own premises. For public use, a general authorisation is required.

Luxembourg: General authorisation required for network and service supply.

Norway: This subsection does not apply for the geographical area within a radius of 20 km from the centre of Ny-Ålesund.

Copyright © Huawei Technologies Co., Ltd. 2010. All rights reserved.

NO WARRANTY

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO CASE SHALL HUAWEI TECHNOLOGIES CO., LTD BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

All the pictures in this guide are for your reference only. The actual appearance and display depend on the mobile phone you purchase.